



8 Commercial Street
Hudson, NH 03051-9984
Tel. 603-324-3240
Fax 603-879-9200
www.fantasyent.com
info@fantasyent.com

Service Bulletin

Making a Personality Disk on Linux Machines

This document describes how to make a Personality disk on Linux machines.

Parts List

This media package includes the following:

- 48.000770 *Making a Personality Disk on Linux Machines* (this document)

Making the Personality Disk

To make the Personality starting at the Ad Rotation, follow these steps:

1. Type the **Q** key to quit the Ad Rotation.
2. Press the **Alt** and **F2** keys to access the Linux operating system.
3. Type **vend** at the username prompt and press the **Enter** key.
4. Type **fotofant** at the password prompt and press the **Enter** key.
5. Insert a blank floppy disk into the floppy drive.
6. Type **cd menu** and press the **Enter** key to change your directory location.
7. Type **./gper** and press the **Enter** key to load the personalities on the disk and return to the system prompt.
8. Remove the floppy from the floppy drive.
9. Type **reboot** and press the **Enter** key. The system reboots and displays the Ad Rotation screens.

Product:

Linux Machines

Operating System:

Linux

P/N:

48.000770

Date:

January 8, 2002